


Network Video

13/02/2025 4:07 pm +10

Network Video Process



Network Video - Vehicle Setup Instructions

Case Contents



1. GoPro Max
2. 2x batteries
3. GoPro dual charger
4. GoPro Remote (if not using phone)
5. SD cards (in case)
6. Selfie Stick
7. Lens caps
8. Suction mount
9. Turn key
10. GoPro case
11. Wet wipes
12. Phone holder (if using phone)
13. 4-port Belkin charger
14. Powerbank
15. Cleaning cloth



Vehicle Mount Setup

1. Attach the selfie stick to the tripod

Extend the selfie stick so it is 50-60cm in length.

Attach the bottom of the selfie stick to the central console of the tripod. Use the turning key to tighten.

Make sure the stick is tight and straight.



In some cases, you might also want to use the level mount but in the Department's testing it was established that connecting the stick directly to the tripod is more secure.



IMPORTANT! Tighten using the turn key to make sure connections are secure.

3. Connect the GoPro

Fold out the connection points from the bottom of the GoPro.



Connect the GoPro to the selfie stick. Insert screw through the fold out connections and tighten.




Remove x2 lens caps and replace with the clear lens caps.






4. Attach tripod to car roof

- Place the tripod in position on top of the vehicle
- Use a wet wipe to clean the area of the vehicle that the suction mounts will be placed on and the suction cups (removing dust).
- Position the arms so that they are spread out evenly and the tripod is level.
- Use the lever to tighten the arms.
- Make sure the Suction Mount clips are raised.
- When in final position, press suction mounts down so there is no gap and then snap clips closed. Do this for each Mount.
- Finally, ensure mounts feel secured.



5. Adjust tripod on roof

Adjust the angle of the stick to ensure the correct part of the road is being filmed. The screen should be facing the back of the car.



Use this lever on the level component to adjust angle.


Setting up the In Car Phone or Tablet Holder



Connect the three pieces of the phone holder together.



Use the suction cup to connect the holder to the inside of the windscreen. Make sure this is in a position that does not affect the drivers view.



Before pressing record make sure that the setting is on **360 Time Lapse with 0.5s interval**.

Network Video - GoPro MAX Recording Settings

GoPro MAX Settings for Recording

1. Check that GPS is on.

- Go to Preferences -> Regional -> GPS
- Make sure that the GPS icon is bright (not greyed out). To see this view, swipe down to open the dashboard page and then swipe down again to see the date/time and connections, including the GPS symbol.
-

Customizing Your GoPro

USING THE DASHBOARD

With your camera in landscape orientation, swipe down to access the Dashboard and Preferences.



DASHBOARD FEATURES

The Dashboard lets you quickly tap the following settings on and off:

- Voice Control
- Camera Beeps
- QuikCapture
- Screen Lock
- Grid
- Orientation Lock

Customizing Your GoPro



CONNECTION STATUS

Check the top of the Dashboard to see your connection status.


- GPS is on (white).
- GPS is off (gray).
- GPS is unavailable (gray).
- Camera is connected to the GoPro app (white).
- Camera is not paired to the GoPro app (gray).
- Camera is not connected to the GoPro app (gray).
- Auto Upload is on and ready (white).
- Auto Upload is off (gray).
- Auto Upload is on but not ready (gray).

2. Set to 360 Time Lapse and check settings

- Set the camera to '360' mode by tapping the icon on bottom left corner. This icon should appear.
- To select time lapse, press the mode button on side of camera until the clock icon and 360 Time Lapse appears.
- To edit Time Lapse settings, tap the middle bottom of the screen which will either say *360 Time Lapse* or *360 Timewarp*. Select *360 Time Lapse*.
- Then select the icon, scroll down to see the Interval option and select 0.5s




Before pressing record make sure that the setting is on **360 Time Lapse with 0.5s interval**.



3. Check battery and time available to record

- The time in top left of screen indicates how much time is available to record footage. For example, this camera has 2 hours and 11 minutes. You should make sure this is greater than the amount of time you expect to record for that day.
- The battery symbol in top right indicates how much battery is left (same as your phone!) Make sure you have the spare battery and ability to charge batteries if doing a lot of recording.



4. Test Recording


- Use the record button and film a short recording.
- Follow instructions below to check the recording has worked.
- Delete this test recording.

□

Network Video - Using the GoPro App or Remote for Recording

Using the GoPro Quik App

 **NOTE!** It is recommended to use the phone app as it has better functionality than the Remote.



Download the GoPro Select MAX Quik app. Open app and select the Connect a GoPro button.

Follow these instructions to allow your GoPro to be connected. Keep the name given to the GoPro.

Once connected you should see this screen. You can operate settings from this screen and start/end recordings.

You can see the view from the GoPro by selecting the Enable Preview button. This requires the WiFi on your phone to be on. When you start recording you cannot see the preview.



IMPORTANT! Do not press record while in Preview mode because you cannot properly see the battery status (%) from this mode.



NOTE! When using preview, it uses the WiFi from the GoPro device, so it doesn't use your data.

Using the GoPro Remote



NOTE! You can either use the Remote of the phone app but you cannot connect both at once.

Pair the Remote

First time pairing to a camera


1. Power off The Remote.
2. On your camera, complete these steps to power on the camera.
3. Tap Preferences -> Connections -> Connect Device -> Remote
4. Power on The Remote.
5. Pair New will appear on The Remote's screen. Press the [Shutter Button] to start pairing.
6. The camera will indicate successful pairing, followed by an indication on The Remote.
7. When successfully paired, The Remote LCD displays the camera settings.



Next time you turn on the remote it will automatically attempt to connect to the GoPro.

Using the Remote

For taking network video, you should only need to use the remote to start/stop recording using the Shutter Button and to check battery life and memory on SD Card.




Network Video - GoPro Max Basics

General maintenance

Here are some more tips to get the best performance from your camera:

- Always use the black lens cap to protect the lenses when you're not using your camera. The lenses are exposed to capture spherical content and are unprotected. Scratches to the lenses are not covered under the warranty.
- Use the clear Protective Lenses if you want added lens protection when you're using your camera. NOTICE: The clear lenses may affect image quality under certain conditions.
- To protect the lenses from damage, do not rest your camera on its front or back side. Be sure the lenses are not resting against any surface.



- To clean the lenses, wipe them with a soft, lint-free cloth. If debris gets stuck between the lens and the trim ring, flush it out with water or air. Do not insert foreign objects around the lenses.
- Your camera is waterproof to 16ft (5m)-no housing needed. Be sure the door is closed before using the camera around water, dirt, or sand.
- Before closing the door, be sure the seal is free of debris. Use a cloth to clean the seal if needed.
- Before opening the doors, be sure that your camera is clean and dry. Rinse your camera with fresh water and dry it with a cloth if needed.
- If sand or debris hardens around the doors, soak your camera in warm tap water for 15 minutes and then rinse thoroughly to remove the debris. Make sure your camera is dry before opening the doors.
- For best audio performance, shake your camera or blow on the mics to remove water and debris from the

microphone holes. Do not use compressed air to blow into the mic holes. This could damage the internal waterproof membranes.


- After every use in salt water, rinse your camera with fresh water, and dry with a soft cloth.

 **WARNING:** The dual lenses of MAX are unprotected and are susceptible to scratches, if not cared for properly. Always store MAX with the provided lens protection and avoid resting the lens on any surface. Scratches to the lens are not covered by the warranty.

GoPro MAX basics


[Link to GoPro MAX online manual](#)

Meet MAX



- | | |
|---|-----------------------|
| 1. Shutter Button  | 5. Door |
| 2. Status Light | 6. USB-C Port |
| 3. Microphone | 7. microSD™ Card Slot |
| 4. Door Lock | 8. Battery |

Meet MAX



- | | |
|----------------------------------|---|
| 9. Camera Lens (Non-Screen Side) | 12. Mode Button  |
| 10. Folding Fingers | 13. Camera Lens (Screen Side) |
| 11. Speaker | 14. Touch Screen |

USING THE TOUCH SCREEN



Tap
Selects an item and turns a setting on or off.



Swipe Left or Right
Switch between Video, Photo, and Time Lapse modes.



Swipe Down From the Edge of the Screen
Open the Dashboard when your camera is in a landscape orientation.



Swipe Up From the Edge of the Screen
See the last photo or video you captured and access the Media Gallery.



Press and Hold the Capture Screen
Turn on and adjust Exposure Control.

Getting to Know Your GoPro

CAPTURE SCREEN

This screen gives you access to your camera's capture settings.



1. Current Mode (Video, Photo, or Time Lapse)
2. Recording Time/Photos Remaining
3. Digital Lens Shortcut
4. HERO/360 Mode Select
5. Battery Status
6. Horizon Lock Shortcut
7. Lens Switch
8. Capture Settings

Heads Up: The capture settings are not available when you rotate your GoPro to take portrait shots. Be sure to choose the settings you want before rotating your camera.

How to change the SD Card and Battery


Unlock the door, slide it down, and flip it open




With your camera off, insert the SD card into the card slot with the label facing the battery compartment



You can eject the card by pressing it into the slot with your fingernail. Insert the battery.



Slide the door all the way up until there's no gap, and then lock it.



NOTICE: Push from the bottom to make sure that the door is closed correctly. Don't use the lock to slide the door closed.

Playing Back Your Media

□

Network Video - How to Record 360 Video Along Network

Recording Process

Map out your day of driving

- It is useful to have some target locations to stop and change batteries/SD Card, and to have a target destination for the end of your day (especially if you plan to stay overnight!)

Recording


- Press the record button on the remote or app to start recording before you start driving.



Record button on app



Record button on Remote



Record button on GoPro

- When you stop, stop the recording.
- If you are stopping for a long time, turn off the GoPro to conserve battery.
- Before you start driving again, press record. Making sure there is no more than 5 to 10 metre gap between recordings.

Using the Log Form

- There is a Log Form provided in the tough-case. Every time you start/stop, use this to record the date & time and a location (if you have latitude/longitude locations this is the best way to record location).
- Also use the Log Form to record where there is a road that is supposed to be logged but is not accessible for

any reason. Provide the reason why the road is not accessible.

Instructions for Driving

Speed Limit

- Should not exceed 70kmh.
- If you go faster than this speed the quality of the image will degrade and the gap between the images increases too much.

Charging batteries

- Using the 360 time lapse mode, a fully charged battery should last 2.5 hours.
- The other battery should be being charged using the power bank and dual charger while capturing footage. Alternatively, can charge using the cigarette lighter adapter.

Check battery and space on SD Card

- You can use the Remote and App to check the status of the battery and the space left on SD Card while you are recording.
- Make sure to proactively change battery/SD card as required. You don't want to drive for miles accidentally without recording!!

Recording two-lane and four-lane roads

- For two-lane roads (one lane for each direction) only take recording for one direction.
- For four-lane roads (two-lanes in each direction), take a recording for both directions.

Time of day

- Try to avoid taking footage early in the morning or late in the afternoon when the sun is low. Ideally, footage should be taken between 9am to 4pm.

End of the Day Tasks

Charge batteries

- Use the dual charger and Belkin four-port charger to charge the GoPro batteries and the powerbank (if necessary).

Secure gear

- Make sure the gear is in a secure place and padlocked.

Clean gear

- In some cases, the gear might get dirty so please clean as needed, so that footage is clear.

Communicate with POM team and office


- If you have any issues with the gear let the POM team know.
- If you are going out for multiple days/overnight you should check in with your local office to let them know your progress.

Network Video - How to Process and Upload Network Video to Mapillary


Create a folder for each date of data on the external hard drive.

Name	Date modified	Type
20240603	3/06/2024 4:29 pm	File folder
20240530	31/05/2024 9:58 am	File folder
20240529	30/05/2024 4:08 pm	File folder
20240523	3/06/2024 4:29 pm	File folder


Use a USB SD Card holder or SD Card holder to access the files on the SD Card. Select the files for one date and copy and paste into the folder you created with the same date.



Open Mapillary. Select the files you want to upload either by dragging and dropping into Mapillary or using the *browse* function.



In Mapillary you will see the PREPARING FOR UPLOAD loading icon.



Once it is ready for upload you will see the GPS track on the map and the name of the video file on the left. If you are happy with the preview, press the *Upload* button.

